

Architect: [Redacted]
 Project Name: [Redacted]
 Date: [Redacted]

Scale: 1/8" = 1'-0"
 Drawing No: [Redacted]

For Planting

Formaldehyde Adhesives

The Right Stuff
 47 Westbrook Road
 London SE17 5SE
 T: 020 7291 1211
 F: 020 7291 8244

Formaldehyde Adhesives



FRONT ELEVATION

MATERIALS KEY

- 01 Brown stone slip, Frown Smoothed Bronze or similar
- 02 Buff rock chip, St Ives Crown Rustica or similar
- 03 Polished bronze anodized aluminum
- 04 Aluminum roofing bronze anodized
- 05 Composite aluminum windows bronze anodized
- 06 Aluminum spandrel panel, dark grey to match windows
- 07 Steel webbed columns, various with level bronze color
- 08 Bronze anodized aluminum mesh, satin and translucent light
- 09 Bronze anodized profile aluminum panel
- 10 Entrance door bronze anodized aluminum, often panel and stainless steel frame
- 11 Horizontal bronze anodized aluminum
- 12 Steel webbed columns, bronze color

Notes: Consult with architect for material samples and finishes.
 Scale: 1/8" = 1'-0"
 Drawing No: [Redacted]
 Date: [Redacted]